

iTroll G3 - Rear exit data cable Surface Mount Drill Template Use 1/4 x 20 screws or bolts

CAUTION:

The threaded holes in the back of the iTroll are only .200 inch (5 mm) deep! Use washers to control how deep your screw or bolt threads in. Excessive fastener depth can damage unit!

